



NLS-EM2039 Series

Embedded 2D Barcode Scan Engine

User Guide



Disclaimer

© 2013 Fujian Newland Auto-ID Tech. Co., Ltd. All rights reserved.

Please read through the manual carefully before using the product and operate it according to the manual. It is advised that you should keep this manual for future reference.

Do not disassemble the device or remove the seal label from the device. Otherwise, Fujian Newland Auto-ID Tech. Co., Ltd. does not assume responsibility for the warranty or replacement.

All pictures in this manual are for reference only and actual product may differ. Regarding to the product modification and update, Fujian Newland Auto-ID Tech. Co., Ltd. reserves the right to make changes to any software or product to improve reliability, function, or design at any time without notice. Besides, the information contained herein is subject to change without prior notice.

The products depicted in this manual may include software copyrighted by Fujian Newland Auto-ID Tech. Co., Ltd or a third party. The user, corporation or individual, shall not duplicate, in whole or in part, distribute, modify, decompile, disassemble, decode, reverse engineer, rent, transfer or sublicense such software without prior written consent from the copyright holders.

This manual is copyrighted. No part of this publication may be reproduced or used in any form without written permission from Newland.

Fujian Newland Auto-ID Tech. Co., Ltd. reserves the right to make final interpretation of the statement above.

Fujian Newland Auto-ID Tech. Co., Ltd.

3F, Building A, No.1, Rujiang Xi Rd., Mawei, Fuzhou, Fujian, P.R. China. 350015.

<http://www.nlscan.com>

Revision History

Version	Description	Date
V1.0.0	Initial release.	June 4, 2013

Table of Contents

Revision History	3
Chapter 1 Getting Started.....	1
Introduction	1
About This Guide	1
Connecting EVK to PC	2
Barcode Scanning	2
Barcode Programming.....	2
Factory Defaults.....	3
Chapter 2 Communication Interfaces	4
TTL-232 Interface	4
Baud Rate	5
Parity Check	6
Data Bit	6
Data Bit & Parity Check	7
Stop Bit	7
Hardware Flow Control.....	8
USB Interface	9
USB Enumeration	9
USB HID-KBW	9
USB Country Keyboard Types	10
Beep on Unknown Character	11
Inter-Keystroke Delay	11
Convert Case.....	12
USB COM Port Emulation	13
Chapter 3 Scan Mode.....	14
Trigger Mode	14
Decode Session Timeout	14
Level Trigger/Pulse Trigger	15
Auto Sleep	15
Sense Mode.....	16

Decode Session Timeout	16
Image Stabilization Timeout	16
Continue after Good Decode.....	17
Timeout between Decodes (Same Barcode)	17
Sensitivity.....	18
Continuous Mode.....	20
Decode Session Timeout	20
Timeout between Decodes.....	20
Chapter 4 Illumination & Aiming.....	21
Illumination.....	21
Aiming.....	22
Chapter 5 Beep & LED Indications	23
Startup Beep.....	23
Beep after Good Decode (Non-programming Barcode)	24
Beep Type.....	24
Beep Volume	25
Beep on Unknown Character	25
Beep after Good Decode (Programming Barcode).....	26
LED Notification for Good Decode	26
Transmit NGR Message	27
Edit NGR Message.....	27
Chapter 6 Data Formatting	28
General Settings.....	29
Enable/Disable All Prefix/Suffix	29
Prefix Sequences.....	29
Custom Prefix	30
Enable/Disable Custom Prefix.....	30
Set Custom Prefix.....	30
AIM ID Prefix.....	31
Code ID Prefix	31
Restore All Default Code IDs.....	31
Modify Code ID	32
Custom Suffix	35

Enable/Disable Custom Suffix	35
Set Custom Suffix	35
Terminating Character Suffix	36
Enable/Disable Terminating Character Suffix	36
Set Terminating Character Suffix	37

Chapter 7 Symbologies 38

General Settings	38
Enable/Disable All Symbologies.....	38
Enable/Disable 1D Symbologies	38
Enable/Disable 2D Symbologies	38
Video Reverse	39
1D Symbologies.....	40
Code 128	40
Restore Factory Defaults.....	40
Enable/Disable Code 128.....	40
Set Length Range for Code 128	40
GS1-128 (UCC/EAN-128)	41
Restore Factory Defaults.....	41
Enable/Disable GS1-128.....	41
Set Length Range for GS1-128.....	41
AIM-128	42
Restore Factory Defaults.....	42
Enable/Disable AIM-128.....	42
Set Length Range for AIM-128	42
EAN-8	43
Restore Factory Defaults.....	43
Enable/Disable EAN-8.....	43
Transmit Check Digit	44
Add-On Code.....	44
Add-On Code Required.....	45
EAN-8 Extension	45
EAN-13	46
Restore Factory Defaults.....	46
Enable/Disable EAN-13.....	46

Transmit Check Digit	46
Add-On Code.....	47
Add-On Code Required.....	47
ISSN.....	48
Restore Factory Defaults.....	48
Enable/Disable ISSN.....	48
Add-On Code.....	49
Add-On Code Required.....	49
ISBN.....	50
Restore Factory Default	50
Enable/Disable ISBN.....	50
Set ISBN Format	50
Add-On Code.....	51
Add-On Code Required.....	51
UPC-E.....	52
Restore Factory Defaults.....	52
Enable/Disable UPC-E	52
Transmit Check Digit	52
Add-On Code.....	53
Add-On Code Required.....	53
Transmit System Character "0"	54
UPC-E Extension	54
UPC-A.....	55
Restore Factory Defaults.....	55
Enable/Disable UPC-A.....	55
Transmit Check Digit	55
Add-On Code.....	56
Add-On Code Required.....	56
Transmit Preamble Character "0".....	57
Interleaved 2 of 5.....	58
Restore Factory Defaults.....	58
Enable/Disable Interleaved 2 of 5	58
Set Length Range for Interleaved 2 of 5.....	58
Parity Check	59
ITF-14	60

ITF-6	61
Matrix 2 of 5	62
Restore Factory Defaults.....	62
Enable/Disable Matrix 2 of 5	62
Set Length Range for Matrix 2 of 5	62
Parity Check	63
Industrial 2 of 5	64
Restore Factory Defaults.....	64
Enable/Disable Industrial 2 of 5	64
Set Length Range for Industrial 2 of 5	64
Parity Check	65
Standard 2 of 5 (IATA 2 of 5)	66
Restore Factory Defaults.....	66
Enable/Disable Standard 25	66
Set Length Range for Standard 25	66
Parity Check	67
Code 39	68
Restore Factory Defaults.....	68
Enable/Disable Code 39.....	68
Transmit Start/Stop Character	68
Set Length Range for Code 39	69
Parity Check	69
Enable/Disable Code 39 Full ASCII	69
Codabar	70
Restore Factory Defaults.....	70
Enable/Disable Codabar	70
Set Length Range for Codabar	70
Parity Check	71
Transmit Start/Stop Character	71
Start/Stop Character Format	72
Code 93	73
Restore Factory Defaults.....	73
Enable/Disable Code 93.....	73
Set Length Range for Code 93	73
Parity Check	74

GS1-Databar (RSS).....	75
Restore Factory Defaults.....	75
Enable/Disable GS1 Databar	75
Transmit Application Identifier "01"	75
Code 11	76
Restore Factory Defaults.....	76
Enable/Disable Code 11.....	76
Set Length Range for Code 11	76
Transmit Check Digit	77
Parity Check	77
Plessey	78
Restore Factory Defaults.....	78
Enable/Disable Plessey.....	78
Set Length Range for Plessey	78
Parity Check	79
MSI-Plessey.....	80
Restore Factory Defaults.....	80
Enable/Disable MSI-Plessey.....	80
Set Length Range for MSI-Plessey.....	80
Transmit Check Digit	81
Parity Check	81
2D Symbolologies.....	82
PDF 417.....	82
Restore Factory Defaults.....	82
Enable/Disable PDF 417	82
Set Length Range for PDF 417.....	82
QR Code.....	83
Restore Factory Defaults.....	83
Enable/Disable QR Code	83
Set Length Range for QR Code	83
Micro QR	83
Data Matrix.....	84
Restore Factory Defaults.....	84
Enable/Disable Data Matrix.....	84
Set Length Range for Data Matrix.....	84

Rectangular Barcode.....	85
Mirror Image	85
Chapter 8 Image Control	86
Ambient Illumination	86
Image Flipping	87
Flip	88
Flip Vertically	88
Flip Horizontally	88
Chapter 9 Troubleshooting	89
FAQ.....	89
Appendix	91
Appendix 1: Factory Defaults Table	91
Appendix 2: AIM ID Table.....	98
Appendix 3: Code ID Table	100
Appendix 4: ASCII Table	101
Appendix 5: Parameter Programming Examples	105
a. Program the Decode Session Timeout	105
b. Program the Time Period from Idle to Sleep.....	105
c. Program the Image Stabilization Timeout	105
d. Program the Timeout between Decodes (Same Barcode)	106
e. Program the Threshold Value of Illumination Change	106
f. Program the Timeout between Decodes.....	106
g. Program the Custom Prefix/Suffix	107
h. Program the Terminating Character Suffix.....	107
i. Program the Code ID.....	107
j. Program the NGR Message	108
k. Program the Length Range (Maximum/Minimum Lengths) for a Symbology	108
Appendix 6: Digit Barcodes	109
Appendix 7: Save/Cancel Barcodes.....	111



0006010

Enter Setup

Chapter 1 Getting Started

Introduction

NLS-EM2039 series embedded 2D barcode scan engines, armed with the Newland patented **UIMG**[®], a computerized image recognition system, bring about a new era of 2D barcode scan engines.

The EM2039s' 2D barcode decoder chip ingeniously blends **UIMG**[®] technology and advanced chip design & manufacturing, which significantly simplifies application design and delivers superior performance and solid reliability with low power consumption.

The 2039s support all mainstream 1D and standard 2D barcode symbologies (e.g., PDF417, QR Code M1/M2/Micro and Data Matrix) as well as GS1-DataBar™(RSS) (Limited/Stacked/Expanded versions). It can read barcodes on virtually any medium - paper, plastic card, mobile phones and LCD displays.

This compact, lightweight engine fits easily into even the most space-constrained equipments such as data collectors, meter readers, ticket validators and PDAs.



About This Guide

This guide provides programming instructions for the EM2039. Users can configure the EM2039 by scanning the programming barcodes included in this manual.

The EM2039 has been properly configured for most applications and can be put into use without further configuration. Users may check the **Factory Defaults Table** in **Appendix** for reference. Throughout the manual, asterisks (**) indicate factory default values.



0006000

** Exit Setup



0006010

Enter Setup

Connecting EVK to PC

The EVK tool is provided to assist users in application development for the EM2039. You can connect the EVK to PC via a USB connection or an RS-232 connection. In case of USB connection, a driver is required if EVK wants to communicate with EM2039 and receive decoded data through virtual serial port.

Barcode Scanning

Powered by area-imaging technology and Newland patented **UIMG**[®] technology, the EM2039 features fast scanning and decoding accuracy. Barcodes rotated at any angle can still be read with ease. When scanning a barcode, simply center the aiming beam or pattern projected by the EM2039 over the barcode.

Barcode Programming

Scanning the **Enter Setup** barcode can enable the engine to enter the setup mode. Then you can scan a number of programming barcodes to configure your engine. To exit the setup mode, scan the **Exit Setup** barcode.

If the engine has exited the setup mode, only some special programming barcodes, such as the **Enter Setup** barcode and **Restore All Factory Defaults** barcode, can be read.



0006010

Enter Setup



0006000

**** Exit Setup**



0006000

**** Exit Setup**



0006010

Enter Setup

Programming barcode data (i.e. the characters under programming barcode) can be transmitted to the Host. Scan the appropriate barcode below to enable or disable the transmission of programming barcode data to the Host.

Restarting the engine will automatically disable the transmission of programming barcode data to the Host.



0002010

Transmit Programming Barcode Data



0002000

**** Do Not Transmit Programming Barcode Data**

Factory Defaults

Scanning the following barcode can restore the engine to the factory defaults. See **Appendix 1: Factory Defaults Table** for more information.

Note: Use this feature with discretion.



0001000

Restore All Factory Defaults



0006000

**** Exit Setup**



0006010
Enter Setup

Chapter 2 Communication Interfaces

The EM2039 provides a TTL-232 interface and a USB interface to communicate with the host device. The host device can receive scanned data and send commands to control the engine or to access/alter the configuration information of the engine via the TTL-232 or USB interface.

TTL-232 Interface

Serial communication interface is usually used when connecting the engine to a host device (like PC, POS). However, to ensure smooth communication and accuracy of data, you need to set communication parameters (including baud rate, parity check, data bit and stop bit) to match the host device.

The serial communication interface provided by the engine is based on TTL-level signals. TTL-232 can be used for most application architectures. For those requiring RS-232, an external conversion circuit is needed. The conversion circuit is available only to some models.



**** Serial Communication**

Default serial communication parameters are listed below. Make sure all parameters match the host requirements.

Parameter	Factory Default
Serial Communication	Standard TTL-232
Baud Rate	9600
Parity Check	None
Data Bits	8
Stop Bits	1
Hardware Flow Control	None



0006000
**** Exit Setup**



0006010

Enter Setup

Baud Rate

Baud rate is the number of bits of data transmitted per second. Set the baud rate to match the Host requirements.



0100030

**** 9600**



0100000

1200



0100050

19200



0100010

2400



0100060

38400



0100020

4800



0100070

57600



0100040

14400



0100080

115200



0006000

**** Exit Setup**



0006010

Enter Setup

Parity Check

When the number of data bits is set to 7, you can only select either **Even Parity** or **Odd Parity**. The **None** option will be regarded as **Even Parity** in this case.



0101000

** None



0101010

Even Parity



0101020

Odd Parity

Data Bit

When the number of data bits is set to 7, you can only select either **Even Parity** or **Odd Parity**.



0103020

7 Data Bits



0103030

** 8 Data Bits



0006000

** Exit Setup



0006010

Enter Setup

Data Bit & Parity Check



0105010

7 Data Bits/Even Parity



0105020

7 Data Bits/Odd Parity



0105030

** 8 Data Bits/ No Parity



0105040

8 Data Bits/Even Parity



0105050

8 Data Bits/Odd Parity

Stop Bit



0102000

** 1 Stop Bit



0102010

2 Stop Bits



0006000

** Exit Setup



0006010

Enter Setup

Hardware Flow Control

If CTS flow control is enabled, the engine determines whether to transmit data based on CTS signal level. When CTS signal is at low level which means the serial port's cache memory of receiving device (such as PC) is full, the engine stops sending data through serial port until CTS signal is set to high level by receiving device. If RTS flow control is enabled, whether the engine receives data or not is dependent on RTS signal level. If the engine is not ready for receiving, it will set RTS signal to low level. When sending device (such as PC) detects it, it will not send data to the engine any more to prevent data loss.

If **No Flow Control** is selected, reception/transmission of serial data will not be influenced by RTS/CTS signal.



0104100

**** No Flow Control**



0104110

RTS Flow Control



0104120

CTS Flow Control



0104130

CTS/RTS Flow Control

Note: Before enabling hardware flow control, make sure that RTS/CTS signal line is contained in RS-232 cable. Without the signal line, serial communication errors will occur.



0006000

**** Exit Setup**



0006010

Enter Setup

USB Interface

USB Enumeration

If the engine is connected to the Host via a USB connection, the engine will be enumerated using S/N or “00000000” after power-up. **Enumeration using S/N** enables the Host to distinguish between engines of same model. **Enumeration using “00000000”** disables the Host from distinguishing between engines of same model.

Driver installation is required for each USB device distinguished from others by the Host in the process of enumeration.



1100210

Enumeration Using S/N



1100200

** Enumeration Using “00000000”

USB HID-KBW

When you connect the engine to the Host via a USB connection, you can enable the **USB HID-KBW** feature by scanning the barcode below. Then engine’s transmission will be simulated as USB keyboard input. The Host receives keystrokes on the virtual keyboard. It works on a Plug and Play basis and no driver is required.



1100020

USB HID-KBW



0006000

** Exit Setup



0006010

Enter Setup

USB Country Keyboard Types

Keyboard layouts vary from country to country. The default setting is 1-U.S. keyboard.



1103001

**** 1 - U.S.**



1103002

2 - Japan



1103003

3 - Denmark



1103004

4 - Finland



1103005

5 - France



1103006

6 - Turkey_F



1103007

7 - Italy



1103008

8 - Norway



0006000

**** Exit Setup**



0006010

Enter Setup

Beep on Unknown Character

Due to the differences in keyboard layouts, some characters contained in barcode data may be unavailable on the selected keyboard. As a result, the engine fails to transmit the unknown characters.

Scan the appropriate barcode below to enable or disable the emission of beep when an unknown character is detected.



1103031

Beep on Unknown Character



1103030

**** Do Not Beep on Unknown Character**

Inter-Keystroke Delay

This parameter specifies the delay between emulated keystrokes.



1103050

**** No Delay**



1103051

Short Delay (20ms)



1103052

Long Delay (40ms)



0006000

**** Exit Setup**



0006010

Enter Setup

Convert Case

Scan the appropriate barcode below to convert barcode data to your desired case.



1103040

**** No Case Conversion**



1103043

Invert Upper and Lower Case Characters



1103041

Convert All to Upper Case



1103042

Convert All to Lower Case

Example: When the **Convert All to Lower Case** feature is enabled, barcode data “AbC” is transmitted as “abc”.



0006000

**** Exit Setup**



0006010

Enter Setup

USB COM Port Emulation

If you connect the engine to the Host via a USB connection, the **USB COM Port Emulation** feature allows the Host to receive data in the way as a serial port does. A driver is required for this feature.



1100060

USB COM Port Emulation



0006000

**** Exit Setup**



0006010

Enter Setup

Chapter 3 Scan Mode

Trigger Mode

If the Trigger Mode is enabled, driving the nTrig pin on the host interface connector low activates a decode session. The session continues until the barcode is decoded or decode session timeout occurs or the active trigger signal is no longer present. For good decode, the engine transmits decoded data via communication port. To activate another session, the Host needs to first negate the trigger, wait 20ms or longer and then drive the nTrig pin low.



0302000

**** Trigger Mode**

Decode Session Timeout

This parameter sets the maximum time decode session continues during a scan attempt. It is programmable in 1ms increments from 0ms to 3,600,000ms. The default setting is 3,000ms. To learn how to program this parameter, see **Appendix 5**.



0313000

Decode Session Timeout



0006000

**** Exit Setup**



0006010

Enter Setup

Level Trigger/Pulse Trigger

Level trigger: Decode session is activated and continued by constant active trigger signal. The decode session ends once the barcode is decoded or decode session timeout occurs.

Pulse trigger: Decode session is activated by electric pulse of trigger signal. The decode session continues until the barcode is decoded or decode session timeout occurs.



0313090

**** Level Trigger**



0313091

Pulse Trigger

Auto Sleep

Auto Sleep allows the engine in the Trigger Mode to automatically enter the sleep or low power mode if no operation or communication is performed for a time period (user programmable). When the engine is in the sleep mode, receiving trigger signal or communication from the Host can awake the engine. The engine returns to full operation within 100ms.



0313060

**** Enable Auto Sleep**



0313070

Disable Auto Sleep

The parameter below specifies how long the engine remains idle (no operation or communication occurs) before it is put into sleep mode. It is programmable in 1ms increments from 0ms to 65,535ms. The default setting is 500ms. To learn how to program this parameter, see **Appendix 5**.



0313050

Time Period from Idle to Sleep



0006000

**** Exit Setup**



0006010

Enter Setup

Sense Mode

If the Sense Mode is enabled, the engine activates a decode session every time it detects a change in ambient illumination. The decode session continues until the barcode is decoded or the decode session timeout occurs.

Driving the nTrig pin on the host interface connector low can also activate a decode session. The decode session continues until the active trigger signal is no longer present or the barcode is decoded or the decode session timeout occurs. The trigger signal needs to be negated before the engine is able to monitor ambient illumination again.



0302010

Sense Mode

Decode Session Timeout

This parameter sets the maximum time decode session continues during a scan attempt. If the timeout occurs or the barcode is decoded, the engine goes back to monitoring ambient illumination. It is programmable in 1ms increments from 0ms to 3,600,000ms. The default setting is 3,000ms. To learn how to program this parameter, see **Appendix 5**.



0313000

Decode Session Timeout

Image Stabilization Timeout

The image stabilization timeout is programmable in 1ms increments from 0ms to 1,600ms. The default setting is 500ms. To learn how to program this parameter, see **Appendix 5**.



0313120

Image Stabilization Timeout



0006000

**** Exit Setup**



0006010

Enter Setup

Continue after Good Decode

Continue after Good Decode: The engine starts next decode session after good decode.

Pause after Good Decode: The engine starts another round of illumination monitoring and image stabilization after good decode.



0313130

**** Pause after Good Decode**



0313131

Continue after Good Decode

Timeout between Decodes (Same Barcode)

Timeout between Decodes (Same Barcode) can avoid undesired rereading of same barcode in a given period of time.

To enable/disable the Timeout between Decodes (Same Barcode), scan the appropriate barcode below.

Enable Timeout between Decodes: Do not allow the engine to re-read same barcode before the timeout between decodes (same barcode) occurs.

Disable Timeout between Decodes: Allow the engine to re-read same barcode.



0313020

**** Disable Timeout between Decodes**



0313030

Enable Timeout between Decodes



0006000

**** Exit Setup**



0006010

Enter Setup

The following parameter sets the timeout between decodes for same barcode. It is programmable in 1ms increments from 0ms to 65,535ms. The default setting is 1,500ms.

To learn how to program this parameter, see **Appendix 5**.



0313010

Timeout between Decodes (Same Barcode)

Sensitivity

Sensitivity specifies the degree of acuteness of the engine's response to changes in ambient illumination. The higher the sensitivity, the lower requirement in illumination change to trigger the engine. You can select an appropriate degree of sensitivity that fits the ambient environment.



0312010

Medium Sensitivity



0312000

Low Sensitivity



0312020

High Sensitivity



0312030

Enhanced Sensitivity



0006000

**** Exit Setup**



0006010

Enter Setup

If the above four options fail to meet your needs, you may program the threshold value of illumination change.

Illumination changes that reaches or surpasses the predefined threshold value will cause the engine to start a decode session. The lower the threshold value, the greater the sensitivity of the engine. The default threshold value is 2.

To learn how to program this parameter, see **Appendix 5**.



0312040

Threshold Value of Illumination Change (1-20)



0006000

**** Exit Setup**



0006010

Enter Setup

Continuous Mode

This mode enables the engine to scan/capture, decode and transmit over and over again.

When the engine is operating in Continuous Mode, barcode reading can be suspended/resumed through control over the trigger signal. When barcode reading is in progress, negating the trigger signal after having maintained it for 30ms or longer will suspend barcode reading; when barcode reading is suspended, performing the same control over the trigger signal will resume barcode reading.



0302020

Continuous Mode

Decode Session Timeout

This parameter sets the maximum time decode session continues during a scan attempt. It is programmable in 1ms increments from 0ms to 3,600,000ms. The default setting is 3,000ms. To learn how to program this parameter, see **Appendix 5**.



0313000

Decode Session Timeout

Timeout between Decodes

This parameter sets the timeout between decode sessions. When a decode session ends, next session will not happen until the timeout between decodes occurs. It is programmable in 1ms increments from 0ms to 65,535ms. The default setting is 1,000ms. To learn how to program this parameter, see **Appendix 5**.



0313040

Timeout between Decodes



0006000

** Exit Setup



0006010

Enter Setup

Chapter 4 Illumination & Aiming

Illumination

A couple of illumination options are provided to improve the lighting conditions during every image capture:

Normal: Illumination LEDs are turned on during image capture.

Always ON: Illumination LEDs keep ON after the engine is powered on.

OFF: Illumination LEDs are OFF all the time.



0200000

**** Normal**



0200020

OFF



0200010

Always ON



0006000

**** Exit Setup**



0006010

Enter Setup

Aiming

When scanning/capturing image, the engine projects an aiming pattern which allows positioning the target barcode within its field of view and thus makes decoding easier.

Normal: The engine projects an aiming pattern only during barcode scanning/capture.

Always ON: Aiming pattern is constantly ON after the engine is powered on.

OFF: Aiming pattern is OFF all the time.



0201000

**** Normal**



0201020

OFF



0201010

Always ON



0006000

**** Exit Setup**



0006010

Enter Setup

Chapter 5 Beep & LED Indications

Startup Beep

If startup beep is enabled, the engine will beep after being turned on.



0204001

**** Enable Startup Beep**



0204000

Disable Startup Beep



0006000

**** Exit Setup**



0006010

Enter Setup

Beep after Good Decode (Non-programming Barcode)

The engine can provide a PWM output to an external driver circuit to drive a beeper after decoding a non-programming barcode. Scan the appropriate barcode below to enable or disable the emission of good decode beep. Beep type (frequency) and volume are also user programmable.



0203010

**** Beep after Good Decode,Non-programming barcode**



0203000

Do Not Beep after Good Decode,Non-programming barcode

Beep Type



0203020

Type 1



0203022

**** Type 3**



0203021

Type 2



0006000

**** Exit Setup**



0006010

Enter Setup

Beep Volume



0203030

**** Loud**



0203032

Low



0203031

Medium

Beep on Unknown Character

Due to the differences in keyboard layouts, some characters contained in barcode data may be unavailable on the selected keyboard (USB HID-KBW). As a result, the engine fails to transmit the unknown characters.

Scan the appropriate barcode below to enable or disable the emission of beep when an unknown character is detected.



1103031

Beep on Unknown Character



1103030

**** Do Not Beep on Unknown Character**



0006000

**** Exit Setup**



0006010

Enter Setup

Beep after Good Decode (Programming Barcode)



0203041

**** Beep after Good Decode, Programming Barcode**



0203040

Do Not Beep after Good Decode, Programming Barcode

LED Notification for Good Decode



0206011

**** Good Decode LED Notification ON**



0206010

Good Decode LED Notification OFF



0006000

**** Exit Setup**



0006010

Enter Setup

Transmit NGR Message

Scan a barcode below to select whether or not to transmit a user-defined NGR (Not Good Read) message when a barcode is not decoded.



0320010

Transmit NGR Message



0320000

**** Do Not Transmit NGR Message**

Edit NGR Message

To edit an NGR message, scan the **Edit NGR Message** barcode and the numeric barcodes corresponding to the ASCII values (decimal) of desired characters and then scan the **Save** barcode.

An NGR message can contain 0-7 characters (ASCII value of character: 0-255).



0320020

Edit NGR Message



0006000

**** Exit Setup**



0006010
Enter Setup

Chapter 6 Data Formatting

In many applications, barcode data needs to be edited and distinguished from one another.

Usually AIM ID and Code ID can be used as identifiers, but in some special cases customized prefix and terminating character suffix like Carriage Return or Line Feed can also be the alternatives.

Data formatting may include:

- ✧ Append AIM ID/Code ID/custom prefix before the decoded data
- ✧ Append custom suffix after the decoded data
- ✧ Append terminating character to the end of the data

The following formats can be used when editing barcode data:

- ✧ [Code ID] + [Custom Prefix] + [AIM ID] + [DATA] + [Custom Suffix] + [Terminating Character]
- ✧ [Custom Prefix] + [Code ID] + [AIM ID] + [DATA] + [Custom Suffix] + [Terminating Character]



0006000
**** Exit Setup**



0006010

Enter Setup

General Settings

Enable/Disable All Prefix/Suffix

Disable All Prefix/Suffix: Transmit barcode data with no prefix/suffix.

Enable All Prefix/Suffix: Allow user to append Code ID prefix, AIM ID prefix, custom prefix/suffix and terminating character to the barcode data before the transmission.



0311010

Enable All Prefix/Suffix



0311000

Disable All Prefix/Suffix

Prefix Sequences



0317010

Code ID+Custom Prefix+AIM ID



0317040

** Custom Prefix+Code ID+AIM ID



0006000

** Exit Setup



0006010

Enter Setup

Custom Prefix

Enable/Disable Custom Prefix

If custom prefix is enabled, you are allowed to append to the data a user-defined prefix that cannot exceed 10 characters.



0305010

Enable Custom Prefix



0305000

** Disable Custom Prefix

Set Custom Prefix

To set a custom prefix, scan the **Set Custom Prefix** barcode and the numeric barcodes representing the hexadecimal values of a desired prefix and then scan the **Save** barcode. Refer to **Appendix 4: ASCII Table** for hexadecimal values of characters.

Note: A custom prefix cannot exceed 10 characters.



0300000

Set Custom Prefix

Example: Set the custom prefix to “CODE”

1. Check the hex values of “CODE” in the ASCII Table. (“CODE”: 43, 4F, 44, 45)
2. Scan the **Enter Setup** barcode.
3. Scan the **Set Custom Prefix** barcode.
4. Scan the numeric barcodes “4”, “3”, “4”, “F”, “4”, “4”, “4” and “5”.
5. Scan the **Save** barcode.
6. Scan the **Exit Setup** barcode.



0006000

** Exit Setup



0006010

Enter Setup

AIM ID Prefix

AIM (Automatic Identification Manufacturers) IDs and ISO/IEC 15424 standards define symbology identifiers and data carrier identifiers. (For the details, see the “**Appendix 2: AIM ID Table**” section). If AIM ID prefix is enabled, the engine will add the symbology identifier before the scanned data after decoding.



0308030

Enable AIM ID Prefix



0308000

** Disable AIM ID Prefix

Code ID Prefix

Code ID can also be used to identify barcode type. Unlike AIM ID, Code ID is user programmable. Code ID can only consist of one or two English letters.



0307010

Enable Code ID Prefix



0307000

** Disable Code ID Prefix

Restore All Default Code IDs

For the information of default Code IDs, see the “**Appendix 3: Code ID Table**” section.



0307020

Restore All Default Code IDs



0006000

** Exit Setup



0006010

Enter Setup

Modify Code ID

Code ID of each symbology can be programmed separately. See the following example to learn how to program a Code ID.

Example: Set the Code ID of PDF417 to “p”

1. Check the hex value of “p” in the ASCII Table. (“p”: 70)
2. Scan the **Enter Setup** barcode.
3. Scan the **Modify PDF417 Code ID** barcode.
4. Scan the numeric barcodes “7” and “0”.
5. Scan the **Save** barcode.
6. Scan the **Exit Setup** barcode.



0005000

Modify PDF417 Code ID



0005030

Modify Data Matrix Code ID



0005010

Modify QR Code Code ID



0004020

Modify Code 128 Code ID



0004030

Modify GS1-128 Code ID



0004210

Modify AIM-128 Code ID



0006000

**** Exit Setup**



0006010

Enter Setup



0004040

Modify EAN-8 Code ID



0004050

Modify EAN-13 Code ID



0004060

Modify UPC-E Code ID



0004070

Modify UPC-A Code ID



0004240

Modify ISBN Code ID



0004230

Modify ISSN Code ID



0004130

Modify Code 39 Code ID



0004170

Modify Code 93 Code ID



0004080

Modify Interleaved 2 of 5 Code ID



0004090

Modify ITF-14 Code ID



0006000

**** Exit Setup**



0006010

Enter Setup



0004100

Modify ITF-6 Code ID



0004150

Modify Codabar Code ID



0004250

Modify Industrial 25 Code ID



0004260

Modify Standard 25 Code ID



0004110

Modify Matrix 25Code ID



0004220

Modify COOP 25 Code ID



0004280

Modify Code 11



0004270

Modify Plessey Code ID



0004290

Modify MSI/Plessey Code ID



0004310

Modify GS1 Databar Code ID



0006000

**** Exit Setup**



0006010

Enter Setup

Custom Suffix

Enable/Disable Custom Suffix

If custom suffix is enabled, you are allowed to append to the data a user-defined suffix that cannot exceed 10 characters.



0306010

Enable Custom Suffix



0306000

** Disable Custom Suffix

Set Custom Suffix

To set a custom suffix, scan the **Set Custom Suffix** barcode and the numeric barcodes representing the hexadecimal values of a desired suffix and then scan the **Save** barcode. Refer to **Appendix 4: ASCII Table** for hexadecimal values of characters.

Note: A custom suffix cannot exceed 10 characters.



0301000

Set Custom Suffix

Example: Set the custom suffix to “CODE”

1. Check the hex values of “CODE” in the ASCII Table. (“CODE”: 43, 4F, 44, 45)
2. Scan the **Enter Setup** barcode.
3. Scan the **Set Custom Suffix** barcode.
4. Scan the numeric barcodes “4”, “3”, “4”, “F”, “4”, “4”, “4” and “5”.
5. Scan the **Save** barcode.
6. Scan the **Exit Setup** barcode.



0006000

** Exit Setup



0006010

Enter Setup

Terminating Character Suffix

A terminating character can be used to mark the end of data, which means nothing can be added after it.

A terminating character suffix can contain one or two characters.

Enable/Disable Terminating Character Suffix

To enable/disable terminating character suffix, scan the appropriate barcode below.



0309010

**** Enable Terminating Character Suffix**



0309000

Disable Terminating Character Suffix



0006000

**** Exit Setup**



0006010

Enter Setup

Set Terminating Character Suffix

The engine provides a shortcut for setting the terminating character suffix to 0x0D or 0x0D,0x0A by scanning the following barcode.



0310010

Terminating Character 0x0D



0310020

** Terminating Character 0x0D,0x0A

To set a terminating character suffix, scan the **Set Terminating Character Suffix** barcode and the numeric barcodes representing the hexadecimal value of a desired terminating character and then scan the **Save** barcode. Refer to **Appendix 4: ASCII Table** for hexadecimal values of terminating characters.

Note: A terminating character suffix cannot exceed 2 characters.



0310000

Set Terminating Character Suffix

Example: Set the terminating character suffix to 0x0D

1. Scan the **Enter Setup** barcode.
2. Scan the **Set Terminating Character Suffix** barcode.
3. Scan the numeric barcodes "0" and "D".
4. Scan the **Save** barcode.
5. Scan the **Exit Setup** barcode.



0006000

** Exit Setup



0006010
Enter Setup

Chapter 7 Symbologies

General Settings

Enable/Disable All Symbologies

If the **Disable All Symbologies** feature is enabled, the engine will not be able to read any non-programming barcodes except the programming barcodes.



0001020
Enable All Symbologies



0001010
Disable All Symbologies

Enable/Disable 1D Symbologies

If the **Disable 1D Symbologies** feature is enabled, the engine will not be able to read any 1D barcodes.



0001040
Enable 1D Symbologies



0001030
Disable 1D Symbologies

Enable/Disable 2D Symbologies

If the **Disable 2D Symbologies** feature is enabled, the engine will not be able to read any 2D barcodes.



0001060
Enable 2D Symbologies



0001050
Disable 2D Symbologies



0006000
** Exit Setup



0006010


Enter Setup

Video Reverse


Regular barcode: Dark image on a bright background.

Inverse barcode: Bright image on a dark background.

The examples of regular barcode and inverse barcode are shown below.



Regular Barcode



Inverse Barcode

Video Reverse is used to allow the engine to read barcodes that are inverted.

Video Reverse ON: Read both regular barcodes and inverse barcodes.

Video Reverse OFF: Read regular barcodes only.

The engine shows a slight decrease in scanning speed when Video Reverse is ON.



0001021

Video Reverse ON



0001011

** Video Reverse OFF



0006000

** Exit Setup



0006010

Enter Setup

1D Symbologies

Code 128

Restore Factory Defaults



0400000

Restore the Factory Defaults of Code 128

Enable/Disable Code 128



0400020

** Enable Code 128



0400010

Disable Code 128

Set Length Range for Code 128



0400030

Set the Minimum Length



0400040

Set the Maximum Length



0006000

** Exit Setup



0006010

Enter Setup

GS1-128 (UCC/EAN-128)

Restore Factory Defaults



0412000

Restore the Factory Defaults of GS1-128

Enable/Disable GS1-128



0412020

** Enable GS1-128



0412010

Disable GS1-128

Set Length Range for GS1-128



0412030

Set the Minimum Length



0412040

Set the Maximum Length



0006000

** Exit Setup



0006010

Enter Setup

AIM-128

Restore Factory Defaults



0423000

Restore the Factory Defaults of AIM-128

Enable/Disable AIM-128



0423020

**** Enable AIM-128**



0423010

Disable AIM-128

Set Length Range for AIM-128



0423030

Set the Minimum Length



0423040

Set the Maximum Length



0006000

**** Exit Setup**



0006010

Enter Setup

EAN-8

Restore Factory Defaults



0401000

Restore the Factory Defaults of EAN-8

Enable/Disable EAN-8



0401020

**** Enable EAN-8**



0401010

Disable EAN-8



0006000

**** Exit Setup**



0006010

Enter Setup

Transmit Check Digit

EAN-8 is 8 digits in length with the last one as its check digit used to verify the accuracy of the data.



0401040

**** Transmit EAN-8 Check Digit**



0401030

Do Not Transmit EAN-8 Check Digit

Add-On Code

An EAN-8 barcode can be augmented with a two-digit or five-digit add-on code to form a new one. In the examples below, the part surrounded by blue dotted line is an EAN-8 barcode while the part circled by red dotted line is add-on code.



1234 567



1234 567 89012



0401060

Enable 2-Digit Add-On Code



0401050

**** Disable 2-Digit Add-On Code**



0401080

Enable 5-Digit Add-On Code



0401070

**** Disable 5-Digit Add-On Code**

Enable 2-Digit Add-On Code/ Enable 5-Digit Add-On Code: The engine decodes a mix of EAN-8 barcodes with and without 2-digit/5-digit add-on codes.

Disable 2-Digit Add-On Code/ Disable 5-Digit Add-On Code: The engine decodes EAN-8 and ignores the add-on code when presented with an EAN-8 plus add-on barcode. It can also decode EAN-8 barcodes without add-on codes.



0006000

**** Exit Setup**



0006010

Enter Setup

Add-On Code Required

When **EAN-8 Add-On Code Required** is selected, the engine will only read EAN-8 barcodes that contain add-on codes.



0401110

EAN-8 Add-On Code Required



0401120

**** EAN-8 Add-On Code Not Required**

EAN-8 Extension

Disable EAN-8 Zero Extend: Transmit EAN-8 barcodes as is.

Enable EAN-8 Zero Extend: Add five leading zeros to decoded EAN-8 barcodes to extend to 13 digits.



0401100

Enable EAN-8 Zero Extend



0401090

**** Disable EAN-8 Zero Extend**



0006000

**** Exit Setup**



0006010

Enter Setup

EAN-13

Restore Factory Defaults



0402000

Restore the Factory Defaults of EAN-13

Enable/Disable EAN-13



0402020

** Enable EAN-13



0402010

Disable EAN-13

Transmit Check Digit



0402040

** Transmit EAN-13 Check Digit



0402030

Do Not Transmit EAN-13 Check Digit



0006000

** Exit Setup



0006010

Enter Setup

Add-On Code

An EAN-13 barcode can be augmented with a two-digit or five-digit add-on code to form a new one.



0402060

Enable 2-Digit Add-On Code



0402050

**** Disable 2-Digit Add-On Code**



0402080

Enable 5-Digit Add-On Code



0402070

**** Disable 5-Digit Add-On Code**

Enable 2-Digit Add-On Code/ Enable 5-Digit Add-On Code: The engine decodes a mix of EAN-13 barcodes with and without 2-digit/5-digit add-on codes.

Disable 2-Digit Add-On Code/ Disable 5-Digit Add-On Code: The engine decodes EAN-13 and ignores the add-on code when presented with an EAN-13 plus add-on barcode. It can also decode EAN-13 barcodes without add-on codes.

Add-On Code Required

When **EAN-13 Add-On Code Required** is selected, the engine will only read EAN-13 barcodes that contain add-on codes.



0402090

EAN-13 Add-On Code Required



0402100

**** EAN-13 Add-On Code Not Required**



0006000

**** Exit Setup**



0006010

Enter Setup

ISSN

Restore Factory Defaults



0421000

Restore the Factory Defaults of ISSN

Enable/Disable ISSN



0421020

Enable ISSN



0421010

**** Disable ISSN**



0006000

**** Exit Setup**



0006010

Enter Setup

Add-On Code

An ISSN barcode can be augmented with a two-digit or five-digit add-on code to form a new one.



0421030

Enable 2-Digit Add-On Code



0421040

**** Disable 2-Digit Add-On Code**



0421050

Enable 5-Digit Add-On Code



0421060

**** Disable 5-Digit Add-On Code**

Enable 2-Digit Add-On Code/ Enable 5-Digit Add-On Code: The engine decodes a mix of ISSN barcodes with and without 2-digit/5-digit add-on codes.

Disable 2-Digit Add-On Code/ Disable 5-Digit Add-On Code: The engine decodes ISSN and ignores the add-on code when presented with an ISSN plus add-on barcode. It can also decode ISSN barcodes without add-on codes.

Add-On Code Required

When **ISSN Add-On Code Required** is selected, the engine will only read ISSN barcodes that contain add-on codes.



0421070

ISSN Add-On Code Required



0421080

**** ISSN Add-On Code Not Required**



0006000

**** Exit Setup**



0006010

Enter Setup

ISBN

Restore Factory Default



0416000

Restore the Factory Defaults of ISBN

Enable/Disable ISBN



0416020

**** Enable ISBN**



0416010

Disable ISBN

Set ISBN Format



0416030

****ISBN-13**



0416040

ISBN-10



0006000

**** Exit Setup**



0006010

Enter Setup

Add-On Code

An ISBN barcode can be augmented with a two-digit or five-digit add-on code to form a new one.



0416050

Enable 2-Digit Add-On Code



0416060

**** Disable 2-Digit Add-On Code**



0416070

Enable 5-Digit Add-On Code



0416080

**** Disable 5-Digit Add-On Code**

Enable 2-Digit Add-On Code/ Enable 5-Digit Add-On Code: The engine decodes a mix of ISBN barcodes with and without 2-digit/5-digit add-on codes.

Disable 2-Digit Add-On Code/ Disable 5-Digit Add-On Code: The engine decodes ISBN and ignores the add-on code when presented with an ISBN plus add-on barcode. It can also decode ISBN barcodes without add-on codes.


Add-On Code Required

When **ISBN Add-On Code Required** is selected, the engine will only read ISBN barcodes that contain add-on codes.



0416090

ISBN Add-On Code Required



0416100

**** ISBN Add-On Code Not Required**



0006000

**** Exit Setup**



0006010

Enter Setup

UPC-E

Restore Factory Defaults



0403000

Restore the Factory Defaults of UPC-E

Enable/Disable UPC-E



0403020

** Enable UPC-E



0403010

Disable UPC-E

Transmit Check Digit



0403040

** Transmit UPC-E Check Digit



0403030

Do Not Transmit UPC-E Check Digit



0006000

** Exit Setup



0006010

Enter Setup

Add-On Code

A UPC-E barcode can be augmented with a two-digit or five-digit add-on code to form a new one.



0403060

Enable 2-Digit Add-On Code



0403050

Enable 2-Digit Add-On Code



0403080

Enable 5-Digit Add-On Code



0403070

**** Disable 5-Digit Add-On Code**

Enable 2-Digit Add-On Code/ Enable 5-Digit Add-On Code: The engine decodes a mix of UPC-E barcodes with and without 2-digit/5-digit add-on codes.

Disable 2-Digit Add-On Code/ Disable 5-Digit Add-On Code: The engine decodes UPC-E and ignores the add-on code when presented with a UPC-E plus add-on barcode. It can also decode UPC-E barcodes without add-on codes.

Add-On Code Required

When **UPC-E Add-On Code Required** is selected, the engine will only read UPC-E barcodes that contain add-on codes.



0403130

UPC-E Add-On Code Required



0403140

**** UPC-E Add-On Code Not Required**



0006000

**** Exit Setup**



0006010

Enter Setup

Transmit System Character “0”

The first character of UPC-E barcode is the system character “0”.



0403100

Transmit System Character “0”



0403090

** Do Not Transmit System Character “0”

UPC-E Extension

Disable UPC-E Extend: Transmit UPC-E barcodes as is.

Enable UPC-E Extend”: Extend UPC-E barcodes to make them compatible in length to UPC-A.



0403120

Enable UPC-E Extend



0403110

** Disable UPC-E Extend



0006000

** Exit Setup



0006010

Enter Setup

UPC-A

Restore Factory Defaults



0404000

Restore the Factory Defaults of UPC-A

Enable/Disable UPC-A



0404020

** Enable UPC-A



0404010

Disable UPC-A

Transmit Check Digit



0404040

** Transmit UPC-A Check Digit



0404030

Do Not Transmit UPC-A Check Digit



0006000

** Exit Setup



0006010
Enter Setup

Add-On Code

A UPC-A barcode can be augmented with a two-digit or five-digit add-on code to form a new one.



Enable 2-Digit Add-On Code



**** Disable 2-Digit Add-On Code**



Enable 5-Digit Add-On Code



**** Disable 5-Digit Add-On Code**

Enable 2-Digit Add-On Code/ Enable 5-Digit Add-On Code: The engine decodes a mix of UPC-A barcodes with and without 2-digit/5-digit add-on codes.

Disable 2-Digit Add-On Code/ Disable 5-Digit Add-On Code: The engine decodes UPC-A and ignores the add-on code when presented with a UPC-A plus add-on barcode. It can also decode UPC-A barcodes without add-on codes.

Add-On Code Required

When **UPC-A Add-On Code Required** is selected, the engine will only read UPC-A barcodes that contain add-on codes.



UPC-A Add-On Code Required



**** UPC-A Add-On Code Not Required**



0006000
**** Exit Setup**



0006010

Enter Setup

Transmit Preamble Character "0"



0404100

Transmit Preamble Character "0"



0404090

** Do not Transmit Preamble Character "0"

Note: The preamble character "0" usually does not appear in printed UPC-A barcodes.



0006000

** Exit Setup



0006010

Enter Setup

Interleaved 2 of 5

Restore Factory Defaults



0405000

Restore the Factory Defaults of Interleaved 2 of 5

Enable/Disable Interleaved 2 of 5



0405020

** Enable Interleaved 2 of 5



0405010

Disable Interleaved 2 of 5

Set Length Range for Interleaved 2 of 5



0405030

Set the Minimum Length



0405040

Set the Maximum Length



0006000

** Exit Setup



0006010

Enter Setup

Parity Check

A check digit is optional for Interleaved 2 of 5 and can be added as the last digit. It is a calculated value used to verify the accuracy of the data.

No Parity Check: The engine transmits Interleaved 2 of 5 barcodes as is.

Do Not Transmit Check Digit After Parity Check: The engine will run a parity check using the last digit of Interleaved 2 of 5 barcode as check digit. Barcodes passing the check will be transmitted except the last digit, whereas those failing it will not be transmitted.

Transmit Check Digit After Parity Check: The engine will run a parity check using the last digit of Interleaved 2 of 5 barcode as check digit. Barcodes passing the check will be transmitted, whereas those failing it will not be transmitted.



0405050

**** No Parity Check**



0405060

Do Not Transmit Check Digit After Parity Check



0405070

Transmit Check Digit After Parity Check

Note: If the **Do Not Transmit Check Digit After Parity Check** option is enabled, Interleaved 2 of 5 barcodes with a length that is less than the configured minimum length after having the check digit excluded will not be decoded. (For example, when the **Do Not Transmit Check Digit After Parity Check** option is enabled and the minimum length is set to 4, Interleaved 2 of 5 barcodes with a total length of 4 characters including the check digit cannot be read.)



0006000

**** Exit Setup**



0006010

Enter Setup

ITF-14

ITF-14 is a special kind of Interleaved 2 of 5 with a length of 14 characters and the last character as the check character.



0405260

Restore the Factory Defaults of ITF-14



0405080

Disable ITF-14



0405090

**** Enable ITF-14 But Do Not Transmit Check Digit**



0405100

Enable ITF-14 and Transmit Check Digit

Note: It is advisable not to enable ITF-14 and Interleaved 2 of 5 at the same time.



0006000

**** Exit Setup**



0006010

Enter Setup

ITF-6

ITF-6 is a special kind of Interleaved 2 of 5 with a length of 6 characters and the last character as the check character.



0405270

Restore the Factory Defaults of ITF-6



0405110

** Disable ITF-6



0405120

Enable ITF-6 But Do Not Transmit Check Digit



0405130

Enable ITF-6 and Transmit Check Digit

Note: It is advisable not to enable ITF-6 and Interleaved 2 of 5 at the same time.



0006000

** Exit Setup



0006010

Enter Setup

Matrix 2 of 5

Restore Factory Defaults



0406000

Restore the Factory Defaults of Matrix 2 of 5

Enable/Disable Matrix 2 of 5



0406020

Enable Matrix 2 of 5



0406010

** Disable Matrix 2 of 5

Set Length Range for Matrix 2 of 5



0406030

Set the Minimum Length



0406040

Set the Maximum Length



0006000

** Exit Setup



0006010

Enter Setup

Parity Check



0406050

No Parity Check



0406060

**** Do Not Transmit Check Digit After Parity Check**



0406070

Transmit Check Digit After Parity Check



0006000

**** Exit Setup**



0006010

Enter Setup

Industrial 2 of 5

Restore Factory Defaults



0417000

Restore the Factory Defaults of Industrial 2 of 5

Enable/Disable Industrial 2 of 5



0417020

**** Enable Industrial 2 of 5**



0417010

Disable Industrial 2 of 5

Set Length Range for Industrial 2 of 5



0417030

Set the Minimum Length



0417040

Set the Maximum Length



0006000

**** Exit Setup**



0006010

Enter Setup

Parity Check



0417050

**** No Parity Check**



0417070

Transmit Check Digit After Parity Check



0417060

Do Not Transmit Check Digit After Parity Check



0006000

**** Exit Setup**



0006010

Enter Setup

Standard 2 of 5 (IATA 2 of 5)

Restore Factory Defaults



0418000

Restore the Factory Defaults of Standard 25

Enable/Disable Standard 25



0418020

**** Enable Standard 25**



0418010

Disable Standard 25

Set Length Range for Standard 25



0418030

Set the Minimum Length



0418040

Set the Maximum Length



0006000

**** Exit Setup**



0006010

Enter Setup

Parity Check



0418050

**** No Parity Check**



0418070

Transmit Check Digit After Parity Check



0418060

Do Not Transmit Check Digit After Parity Check



0006000

**** Exit Setup**



0006010

Enter Setup

Code 39

Restore Factory Defaults



0408000

Restore the Factory Defaults of Code 39

Enable/Disable Code 39



0408020

**** Enable Code 39**



0408010

Disable Code 39

Transmit Start/Stop Character



0408090

**** Transmit Start/Stop Character**



0408080

Do not Transmit Start/Stop Character



0006000

**** Exit Setup**



0006010

Enter Setup

Set Length Range for Code 39



0408030

Set the Minimum Length



0408040

Set the Maximum Length

Parity Check



0408050

** No Parity Check



0408070

Transmit Check Digit After Parity Check



0408060

Do Not Transmit Check Digit After Parity Check


Enable/Disable Code 39 Full ASCII

The engine can be configured to identify all ASCII characters by scanning the appropriate barcode below.



0408110

** Enable Code 39 Full ASCII



0408100

Disable Code 39 Full ASCII



0006000

** Exit Setup



0006010

Enter Setup

Codabar

Restore Factory Defaults



0409000

Restore the Factory Defaults of Codabar

Enable/Disable Codabar



0409020

**** Enable Codabar**



0409010

Disable Codabar

Set Length Range for Codabar



0409030

Set the Minimum Length



0409040

Set the Maximum Length



0006000

**** Exit Setup**



0006010

Enter Setup

Parity Check



0409050

**** No Parity Check**



0409070

Transmit Check Digit After Parity Check



0409060

Do Not Transmit Check Digit After Parity Check

Transmit Start/Stop Character



0409090

**** Transmit Start/Stop Character**



0409080

Do not Transmit Start/Stop Character



0006000

**** Exit Setup**



0006010

Enter Setup

Start/Stop Character Format

You can choose your desired start/stop character format by scanning the appropriate barcode below.



0409100

**** ABCD/ABCD as the Start/Stop Character**



0409110

ABCD/TN*E as the Start/Stop Character



0409120

Start/Stop Character in Uppercase



0409130

Start/Stop Character in Lowercase



0006000

**** Exit Setup**



0006010

Enter Setup

Code 93

Restore Factory Defaults



0410000

Restore the Factory Defaults of Code 93

Enable/Disable Code 93



0410020

** Enable Code 93



0410010

Disable Code 93

Set Length Range for Code 93



0410030

Set the Minimum Length



0410040

Set the Maximum Length



0006000

** Exit Setup



0006010

Enter Setup

Parity Check



0410050

No Parity Check



0410060

**** Do Not Transmit Check Digit After Parity Check**



0410070

Transmit Check Digit After Parity Check



0006000

**** Exit Setup**



0006010

Enter Setup

GS1-Databar (RSS)

Restore Factory Defaults



0413000

Restore the Factory Defaults of GS1-Databar

Enable/Disable GS1 Databar



0413020

** Enable GS1-DataBar



0413010

Disable GS1-DataBar

Transmit Application Identifier "01"



0413060

** Transmit Application Identifier "01"



0413050

Do Not Transmit Application Identifier "01"



0006000

** Exit Setup



0006010

Enter Setup

Code 11

Restore Factory Defaults



0415000

Restore the Factory Defaults of Code 11

Enable/Disable Code 11



0415020

**** Enable Code 11**



0415010

Disable Code 11

Set Length Range for Code 11



0415030

Set the Minimum Length



0415040

Set the Maximum Length



0006000

**** Exit Setup**



0006010

Enter Setup

Transmit Check Digit



0415120

Transmit Check Digit



0415110

** Do Not Transmit Check Digit

Parity Check



0415050

No Parity Check



0415060

** One Check Digit, MOD11



0415070

Two Check Digits, MOD11/MOD11



0415080

Two Check Digits, MOD11/MOD9



0415090

One Check Digit, MOD11 (Len<=10)
Two Check Digits, MOD11/MOD11 (Len>10)



0415100

One Check Digit, MOD11 (Len<=10)
Two Check Digits, MOD11/MOD9 (Len>10)



0006000

** Exit Setup



0006010

Enter Setup

Plessey

Restore Factory Defaults



0419000

Restore the Factory Defaults of Plessey

Enable/Disable Plessey



0419020

**** Enable Plessey**



0419010

Disable Plessey

Set Length Range for Plessey



0419030

Set the Minimum Length



0419040

Set the Maximum Length



0006000

**** Exit Setup**



0006010

Enter Setup

Parity Check



0419050

No Parity Check



0419060

**** Do Not Transmit Check Digit After Parity Check**



0419070

Transmit Check Digit After Parity Check



0006000

**** Exit Setup**



0006010

Enter Setup

MSI-Plessey

Restore Factory Defaults



0420000

Restore the Factory Defaults of MSI-Plessey

Enable/Disable MSI-Plessey



0420020

**** Enable MSI-Plessey**



0420010

Disable MSI-Plessey

Set Length Range for MSI-Plessey



0420030

Set the Minimum Length



0420040

Set the Maximum Length



0006000

**** Exit Setup**



0006010

Enter Setup

Transmit Check Digit



0420100

Transmit Check Digit



0420090

** Do Not Transmit Check Digit

Parity Check



0420050

No Parity Check



0420060

** One Check Digit, MOD10



0420070

Two Check Digits, MOD10/MOD10



0420080

Two Check Digits, MOD10/MOD11



0006000

** Exit Setup



0006010

Enter Setup

2D Symbologies

PDF 417

Restore Factory Defaults



0501000

Restore the Factory Defaults of PDF 417

Enable/Disable PDF 417



0501020

** Enable PDF 417



0501010

Disable PDF 417

Set Length Range for PDF 417



0501030

Set the Minimum Length



0501040

Set the Maximum Length



0006000

** Exit Setup



0006010

Enter Setup

QR Code

Restore Factory Defaults



0502000

Restore the Factory Defaults of QR Code

Enable/Disable QR Code



0502020

** Enable QR Code



0502010

Disable QR Code

Set Length Range for QR Code



0502030

Set the Minimum Length



0502040

Set the Maximum Length

Micro QR



0502110

** Enable Micro QR



0502100

Disable Micro QR



0006000

** Exit Setup



0006010

Enter Setup

Data Matrix

Restore Factory Defaults



0504000

Restore the Factory Defaults of Data Matrix

Enable/Disable Data Matrix



0504020

**** Enable Data Matrix**



0504010

Disable Data Matrix

Set Length Range for Data Matrix



0504030

Set the Minimum Length



0504040

Set the Maximum Length



0006000

**** Exit Setup**



0006010

Enter Setup

Rectangular Barcode



0504110

**** Enable Rectangular Barcode**



0504100

Disable Rectangular Barcode

Mirror Image



0504331

**** Decode Mirror Images**



0504330

Do Not Decode Mirror Images



0006000

**** Exit Setup**



0006010

Enter Setup

Chapter 8 Image Control

Ambient Illumination

Ambient lighting conditions may vary from one operating environment to another, such as fluorescent lit warehouses or sunlit open spaces. Fluorescent lights may flicker when using AC power source in 50-60Hz. Usually indoor illuminance is around 1,000 lux while outdoor illuminance may reach 60,000 lux or even over 100,000 lux.

Two options are provided for ambient illumination settings:

Normal Illuminance: applicable to most indoor/outdoor environments.

High Illuminance: applicable to special environments with super-intense light source.

Change to this settings will not take effect until the engine reboots or wakes up from sleep.



0313150

**** Normal Illuminance (0~60000lux)**



0313151

High Illuminance (60000~120000lux)



0006000

**** Exit Setup**



0006010

Enter Setup

Image Flipping

The user may get reversed images when the engine is installed in non-standard ways. When it happens, image flipping can be used to right the “wrong”.

The following figures illustrate standard image and three flipped images.

- ✧ Fig.8-1 Standard Image: Image the engine should get when it is installed properly and no reflector is used in its optical imaging system.
- ✧ Fig.8-2 Horizontal Flipped Image: It happens when horizontal reflection occurs along the optical path. To get standard images, enable the **Flip Horizontally** option.
- ✧ Fig.8-3 Vertical Flipped Image: It happens when vertical reflection occurs along the optical path. To get standard images, enable the **Flip Vertically** option.
- ✧ Fig.8-4 Horizontal and Vertical Flipped Image: It happens when the engine is installed upside down. To get standard images, enable the **Flip Horizontally and Vertically** option.



Fig.8-1 Standard Image



Fig.8-2 Horizontal Flipped Image



Fig.8-3 Vertical Flipped Image



Fig.8-4 Horizontal and Vertical Flipped Image



0006000

** Exit Setup



0006010

Enter Setup

Flip



0202000

**** Do Not Flip**



0202030

Flip Vertically



0202031

Flip Horizontally



0202032

Flip Horizontally and Vertically

Flip Vertically



0202033

Flip Vertically



0202034

Do Not Flip Vertically

Flip Horizontally



0202035

Flip Horizontally



0202036

Do Not Flip Horizontally



0006000

**** Exit Setup**

Chapter 9 Troubleshooting

FAQ

Problem: Barcodes cannot be read.

Solution:

1. Find out the barcode type and verify that the barcode type is enabled. If the barcode parameters include parity check, select the No Parity Check option.
2. If you do not know the barcode type, enable all symbologies.
3. If they are inverse barcodes (bright images on a dark background), enable the Video Reverse feature.

Problem: Incorrect output.

Solution:

1. If this problem happens to all barcodes and additional characters appear before/after barcode data, disable all prefix/suffix.
2. If this problem only happens to some barcodes and matches one of the following situations:
 - a) incomplete barcode data: Enable the parity check.
 - b) both the first and last characters are asterisks (*): Disable the transmission of start/stop characters of Code 39.
 - c) "a" transmitted as "+A": Enable Code 39 Full ASCII.

Problem: Barcodes can be read, but cannot be displayed.

Solution: Modify the serial port properties or change the communication mode.

1. Serial communication:

Verify that the parameters (such as baud rate, data bit and stop bit) settings match the host requirements.
2. USB communication:
 - a. USB HID-KBW: No driver is required. It can provide output to a text file, but only alphanumeric characters can be displayed.
 - b. USB COM Port Emulation: A driver is required. You can get the output via a serial port debug tool.

Problem: Illumination and aiming beams are OFF.

Solution:

1. Verify that the engine is properly powered up.
2. Send “?” to the engine. If the engine returns a reply of “!”, then send programming commands to turn on illumination and aimer.

Problem: Carriage Return/Line Feed settings.

Solution: See the “**Terminating Character Suffix**” section in Chapter 7.

Appendix

Appendix 1: Factory Defaults Table

Parameter		Factory Default	Remark
Programming Barcode			
Barcode Programming		Disabled	
Programming Barcode Data		Do not send	
Communication Settings			
Interface		TTL-232	Options: TTL-232, USB HID-KBW, USB COM Port Emulation
TTL-232	Baud Rate	9600	
	Parity Check	None	
	Data Bit	8	
	Stop Bit	1	
	Hardware Flow Control	No flow control	
HID-KBW	USB Country Keyboard Type	U.S.	
	Convert Case	No conversion	
	Inter-Keystroke Delay	No delay	
	Beep on Unknown Character	Do not beep	
Scan Mode			
Scan Mode		Trigger mode	Options: Trigger mode, Sense mode, Continuous mode.
Trigger Mode	Decode Session Timeout	3,000ms	Applicable to all three scan modes. 0~3,600,000ms
	Trigger Condition	Electric level	
	Auto Sleep	Enabled	
	Time Period from Idle to Sleep	500ms	0~65,535ms
Sense Mode	Decode Session Timeout	3,000ms	Applicable to all three scan modes. 0~3,600,000ms
	Image Stabilization Timeout	500ms	0~1,600ms
	Operation after Good Decode	Pause after good decode	
	Timeout between Decodes (Same Barcode)	Disabled 1,500ms	0~65,535ms
	Threshold Value of Illumination Change	2	1~20

Parameter		Factory Default	Remark
Continuous Mode	Decode Session Timeout	3,000ms	Applicable to all three scan modes. 0~3,600,000ms
	Timeout between Decodes	1,000ms	0~65,535ms
Illumination & Aiming			
Illumination		Normal	
Aiming		Normal	
Beep & LED Indications			
Startup Beep		Enabled	
Beep after Good Decode (Non-Programming Barcode)	Notification	Enabled	
	Beep Type	Type 3	
	Beep Volume	Loud	
Beep after Good Decode (Programming Barcode)		Enabled	
LED Notification for Good Decode		Enabled	
NGR (Not Good Read) Message		Do not transmit	
		None	
Data Formatting			
Prefix Sequence		Custom Prefix+Code ID+AIM ID	
Custom Prefix		Disabled	
		None	
AIM ID Prefix		Disabled	
Code ID Prefix		Disabled	
Custom Suffix		Disabled	
		None	
Terminating Character Suffix		Enabled	
		0x0D, 0x0A	Carriage Return /Line Feed
Image Control			
Ambient Illumination		Normal illuminance	
Image Flipping		Do not flip	

Parameter	Factory Default	Remark
Symbologies		
Video Reverse	Disabled	Applicable to all symbologies.
Code 128		
Code 128	Enabled	
Maximum Length	127	
Minimum Length	1	
GS1-128 (UCC/EAN-128)		
GS1-128	Enabled	
Maximum Length	127	
Minimum Length	1	
AIM-128		
AIM-128	Enabled	
Maximum Length	127	
Minimum Length	1	
EAN-8		
EAN-8	Enabled	
Check Digit	Transmit	
2-Digit Add-On Code	Disabled	
5-Digit Add-On Code	Disabled	
Add-On Code	Not required	
Extend to EAN-13	Disabled	
EAN-13		
EAN-13	Enabled	
Check Digit	Transmit	
2-Digit Add-On Code	Disabled	
5-Digit Add-On Code	Disabled	
Add-On Code	Not required	
ISSN		
ISSN	Disabled	
2-Digit Add-On Code	Disabled	
5-Digit Add-On Code	Disabled	
Add-On Code	Not required	

Parameter	Factory Default	Remark
ISBN		
ISBN	Enabled	
ISBN Format	ISBN-13	
2-Digit Add-On Code	Disabled	
5-Digit Add-On Code	Disabled	
Add-On Code	Not required	
UPC-E		
UPC-E	Enabled	
Check Digit	Transmit	
2-Digit Add-On Code	Disabled	
5-Digit Add-On Code	Disabled	
Add-On Code	Not required	
Extend to UPC-A	Disabled	
System Character "0"	Do not transmit	
UPC-A		
UPC-A	Enabled	
Check Digit	Transmit	
2-Digit Add-On Code	Disabled	
5-Digit Add-On Code	Disabled	
Add-On Code	Not required	
Preamble Character "0"	Do not transmit	
Interleaved 2 of 5		
Interleaved 2 of 5	Enabled	
Parity Check	None	
Check Digit	Do not transmit	
Maximum Length	100	
Minimum Length	6	
ITF-6		
ITF-6	Disabled	
Check Digit	Do not transmit	

Parameter	Factory Default	Remark
ITF-14		
ITF-14	Enabled	
Check Digit	Do not transmit	
Matrix 2 of 5		
Matrix 2 of 5	Disabled	
Parity Check	Enabled	
Check Digit	Do not transmit	
Maximum Length	127	
Minimum Length	6	
Industrial 2 of 5		
Industrial 2 of 5	Enabled	
Parity Check	None	
Check Digit	Do not transmit	
Maximum Length	127	
Minimum Length	6	
Standard 2 of 5		
Standard 2 of 5	Enabled	
Parity Check	None	
Check Digit	Do not transmit	
Maximum Length	127	
Minimum Length	6	
Code 39		
Code 39	Enabled	
Parity Check	None	
Check Digit	Do not transmit	
Start/Stop Character	Transmit	
Code 39 Full ASCII	Enabled	
Maximum Length	127	
Minimum Length	4	

Parameter	Factory Default	Remark
Codabar		
Codabar	Enabled	
Parity Check	None	
Check Digit	Do not transmit	
Start/Stop Character	Do not transmit	
Start/Stop Character Format	ABCD/ABCD	
Maximum Length	127	
Minimum Length	1	
Code 93		
Code 93	Enabled	
Parity Check	Enabled	
Check Digit	Do not transmit	
Maximum Length	127	
Minimum Length	3	
GS1 Databar		
GS1 Databar	Enabled	
Application Identifier "01"	Transmit	
Code 11		
Code 11	Enabled	
Parity Check	One check digit, MOD11	
Check Digit	Do not transmit	
Maximum Length	127	
Minimum Length	2	
Plessey		
Plessey	Enabled	
Parity Check	Enabled	
Check Digit	Do not transmit	
Maximum Length	127	
Minimum Length	1	

Parameter	Factory Default	Remark
MSI-Plessey		
MSI-Plessey	Enabled	
Parity Check	One check digit, MOD10	
Check Digit	Do not transmit	
Maximum Length	127	
Minimum Length	2	
PDF 417		
PDF 417	Enabled	
Maximum Length	2710	
Minimum Length	1	
QR Code		
QR Code	Enabled	
Micro QR	Enabled	
Maximum Length	7089	
Minimum Length	1	
Data Matrix		
Data Matrix	Enabled	
Rectangular Barcode	Enabled	
Mirror Image	Decode	
Maximum Length	3116	
Minimum Length	1	

Appendix 2: AIM ID Table

Symbology	AIM ID	Remark
EAN-13]E0	Standard EAN-13
]E3	EAN-13 + 2/5-Digit Add-On Code
EAN-8]E4	Standard EAN-8
]E4...]E1...	EAN-8 + 2-Digit Add-On Code
]E4...]E2...	EAN-8 + 5-Digit Add-On Code
UPC-E]E0	Standard UPC-E
]E3	UPC-E + 2/5-Digit Add-On Code
UPC-A]E0	Standard UPC-A
]E3	UPC-A + 2/5-Digit Add-On Code
Code 128]C0	Standard Code 128
GS1-128 (UCC/EAN-128)]C1	FNC1 is the character right after the start character
AIM-128]C2	FNC1 is the 2nd character after the start character
ISBT-128]C4	
Interleaved 2 of 5]I0	No parity check
]I1	Transmit check digit after parity check
]I3	Do not transmit check digit after parity check
ITF-6]I1	Transmit check digit
]I3	Do not transmit check digit
ITF-14]I1	Transmit check digit
]I3	Do not transmit check digit
Industrial 2 of 5]S0	Not specified
Standard 2 of 5]R0	No parity check
]R8	One check digit, MOD10; do not transmit check digit
]R9	One check digit, MOD10; transmit check digit
Code 39]A0	Transmit barcodes as is; Full ASCII disabled; no parity check
]A1	One check digit, MOD43; transmit check digit
]A3	One check digit, MOD43; do not transmit check digit
]A4	Full ASCII enabled; no parity check
]A5	Full ASCII enabled; transmit check digit
]A7	Full ASCII enabled; do not transmit check digit
Codabar]F0	Standard Codabar
]F2	Transmit check digit after parity check
]F4	Do not transmit check digit after parity check

Symbology	AIM ID	Remark
Code 93]G0	Standard Code 93
Code 11]H0	One check digit MOD11; transmit check digit
]H1	Two check digits, MOD11/MOD11; transmit check digit
]H3	Do not transmit check digit after parity check
]H9	No parity check
GS1-DataBar (RSS)]e0	Standard GS1-DataBar
Plessey]P0	Standard Plessey
MSI-Plessey]M0	One check digit, MOD10; transmit check digit
]M1	One check digit, MOD10; do not transmit check digit
]M8	Two check digits
]M9	No parity check
Matrix 2 of 5]X0	Specified by the manufacturer
]X1	No parity check
]X2	One check digit, MOD10; transmit check digit
]X3	One check digit, MOD11; do not transmit check digit
ISBN]X4	Standard ISBN
ISSN]X5	Standard ISSN
PDF417]L0	Comply with 1994 PDF417 specifications
Data Matrix]d0	ECC000 - ECC140
]d1	ECC200
]d2	ECC200, FNC1 is the 1st or 5th character after the start character
]d3	ECC200, FNC1 is the 2nd or 6th character after the start character
]d4	ECC200, ECI included
]d5	ECC200, FNC1 is the 1st or 5th character after the start character, ECI included
]d6	ECC200, FNC1 is the 2nd or 6th character after the start character, ECI included
QR Code]Q0	QR1
]Q1	2005 version, ECI excluded
]Q2	2005 version, ECI included
]Q3	QR Code 2005, ECI excluded, FNC1 is the 1st character after the start character
]Q4	QR Code 2005, ECI included, FNC1 is the 1st character after the start character
]Q5	QR Code 2005, ECI excluded, FNC1 is the 2nd character after the start character
]Q6	QR Code 2005, ECI included, FNC1 is the 2nd character after the start character

Reference: ISO/IEC 15424:2008 Information technology – Automatic identification and data capture techniques – Data Carrier Identifiers (including Symbology Identifiers).

Appendix 3: Code ID Table

Symbology	Code ID
Code 128	j
GS1-128(UCC/EAN-128)	j
AIM-128	f
EAN-8	d
EAN-13	d
ISSN	n
ISBN	B
UPC-E	c
UPC-A	c
Interleaved 2 of 5	e
ITF-6	e
ITF-14	e
Matrix 2 of 5	v
Industrial 2 of 5	D
Standard 2 of 5	s
Code 39	b
Codabar	a
Code 93	i
Code 11	H
Plessey	p
MSI-Plessey	m
GS1 Databar	R
PDF417	r
QR Code	Q
Data Matrix	u

Appendix 4: ASCII Table

Hex	Dec	Char
00	0	NUL (Null char.)
01	1	SOH (Start of Header)
02	2	STX (Start of Text)
03	3	ETX (End of Text)
04	4	EOT (End of Transmission)
05	5	ENQ (Enquiry)
06	6	ACK (Acknowledgment)
07	7	BEL (Bell)
08	8	BS (Backspace)
09	9	HT (Horizontal Tab)
0a	10	LF (Line Feed)
0b	11	VT (Vertical Tab)
0c	12	FF (Form Feed)
0d	13	CR (Carriage Return)
0e	14	SO (Shift Out)
0f	15	SI (Shift In)
10	16	DLE (Data Link Escape)
11	17	DC1 (XON) (Device Control 1)
12	18	DC2 (Device Control 2)
13	19	DC3 (XOFF) (Device Control 3)
14	20	DC4 (Device Control 4)
15	21	NAK (Negative Acknowledgement)
16	22	SYN (Synchronous Idle)
17	23	ETB (End of Trans. Block)
18	24	CAN (Cancel)
19	25	EM (End of Medium)
1a	26	SUB (Substitute)
1b	27	ESC (Escape)
1c	28	FS (File Separator)
1d	29	GS (Group Separator)

Hex	Dec	Char
1e	30	RS (Request to Send)
1f	31	US (Unit Separator)
20	32	SP (Space)
21	33	! (Exclamation Mark)
22	34	" (Double Quote)
23	35	# (Number Sign)
24	36	\$ (Dollar Sign)
25	37	% (Percent)
26	38	& (Ampersand)
27	39	` (Single Quote)
28	40	((Right / Closing Parenthesis)
29	41) (Right / Closing Parenthesis)
2a	42	* (Asterisk)
2b	43	+ (Plus)
2c	44	, (Comma)
2d	45	- (Minus / Dash)
2e	46	. (Dot)
2f	47	/ (Forward Slash)
30	48	0
31	49	1
32	50	2
33	51	3
34	52	4
35	53	5
36	54	6
37	55	7
38	56	8
39	57	9
3a	58	: (Colon)
3b	59	; (Semi-colon)
3c	60	< (Less Than)
3d	61	= (Equal Sign)

Hex	Dec	Char
3e	62	> (Greater Than)
3f	63	? (Question Mark)
40	64	@ (AT Symbol)
41	65	A
42	66	B
43	67	C
44	68	D
45	69	E
46	70	F
47	71	G
48	72	H
49	73	I
4a	74	J
4b	75	K
4c	76	L
4d	77	M
4e	78	N
4f	79	O
50	80	P
51	81	Q
52	82	R
53	83	S
54	84	T
55	85	U
56	86	V
57	87	W
58	88	X
59	89	Y
5a	90	Z
5b	91	[(Left / Opening Bracket)
5c	92	\ (Back Slash)
5d	93] (Right / Closing Bracket)

Hex	Dec	Char
5e	94	^ (Caret / Circumflex)
5f	95	_ (Underscore)
60	96	' (Grave Accent)
61	97	a
62	98	b
63	99	c
64	100	d
65	101	e
66	102	f
67	103	g
68	104	h
69	105	i
6a	106	j
6b	107	k
6c	108	l
6d	109	m
6e	110	n
6f	111	o
70	112	p
71	113	q
72	114	r
73	115	s
74	116	t
75	117	u
76	118	v
77	119	w
78	120	x
79	121	y
7a	122	z
7b	123	{ (Left/ Opening Brace)
7c	124	(Vertical Bar)
7d	125	} (Right/Closing Brace)
7e	126	~ (Tilde)
7f	127	DEL (Delete)

Appendix 5: Parameter Programming Examples

The following examples show you how to program parameters by scanning programming barcodes.

a. Program the Decode Session Timeout

Example: Set the decode session timeout to 1500ms

1. Scan the **Enter Setup** barcode.
2. Scan the **Decode Session Timeout** barcode. (See the “**Decode Session Timeout**” section in Chapter 3)
3. Scan the numeric barcodes “1”, “5”, “0” and “0”.
4. Scan the **Save** barcode.
5. Scan the **Exit Setup** barcode. (If you still need to program other parameter/feature, skip this step.)

b. Program the Time Period from Idle to Sleep

Example: Set the time period from idle to sleep to 500ms

1. Scan the **Enter Setup** barcode.
2. Scan the **Time Period from Idle to Sleep** barcode. (See the “**Auto Sleep**” section in Chapter 3)
3. Scan the numeric barcodes “5”, “0” and “0”.
4. Scan the **Save** barcode.
5. Scan the **Exit Setup** barcode. (If you still need to program other parameter/feature, skip this step.)

c. Program the Image Stabilization Timeout

Example: Set the image stabilization timeout to 500ms

1. Scan the **Enter Setup** barcode.
 2. Scan the **Image Stabilization Timeout** barcode. (See the “**Image Stabilization Timeout**” section in Chapter 3)
 3. Scan the numeric barcodes “5”, “0” and “0”.
 4. Scan the **Save** barcode.
 5. Scan the **Exit Setup** barcode. (If you still need to program other parameter/feature, skip this step.)
-

d. Program the Timeout between Decodes (Same Barcode)

Example: Set the timeout between decodes (same barcode) to 1000ms

1. Scan the **Enter Setup** barcode.
2. Scan the **Timeout between Decodes (Same Barcode)** barcode. (See the “**Timeout between Decodes (Same Barcode)**” section in Chapter 3)
3. Scan the numeric barcodes “1”, “0”, “0” and “0”.
4. Scan the **Save** barcode.
5. Scan the **Exit Setup** barcode. (If you still need to program other parameter/feature, skip this step.)

e. Program the Threshold Value of Illumination Change

Example: Set the threshold value of illumination change to 4

1. Scan the **Enter Setup** barcode.
2. Scan the **Threshold Value of Illumination Change** barcode. (See the “**Sensitivity**” section in Chapter 3)
3. Scan the numeric barcode “4”.
4. Scan the **Save** barcode.
5. Scan the **Exit Setup** barcode. (If you still need to program other parameter/feature, skip this step.)

f. Program the Timeout between Decodes

Example: Set the timeout between decodes to 500ms

1. Scan the **Enter Setup** barcode.
 2. Scan the **Timeout between Decodes** barcode. (See the “**Timeout between Decodes**” section in Chapter 3)
 3. Scan the numeric barcodes “5”, “0” and “0”.
 4. Scan the **Save** barcode.
 5. Scan the **Exit Setup** barcode. (If you still need to program other parameter/feature, skip this step.)
-

g. Program the Custom Prefix/Suffix

Example: Set the custom prefix to “CODE”

1. Check the hex values of “CODE” in the ASCII Table. (“CODE”: 43, 4F, 44, 45)
2. Scan the **Enter Setup** barcode.
3. Scan the **Set Custom Prefix** barcode. (See the “**Set Custom Prefix**” section in Chapter 6)
4. Scan the numeric barcodes “4”, “3”, “4”, “F”, “4”, “4”, “4” and “5”.
5. Scan the **Save** barcode.
6. Scan the **Exit Setup** barcode. (If you still need to program other parameter/feature, skip this step.)

h. Program the Terminating Character Suffix

Example: Set the terminating character suffix to 0x0D

1. Scan the **Enter Setup** barcode.
2. Scan the **Set Terminating Character Suffix** barcode. (See the “**Set Terminating Character Suffix**” section in Chapter 6)
3. Scan the numeric barcodes “0” and “D”.
4. Scan the **Save** barcode.
5. Scan the **Exit Setup** barcode. (If you still need to program other parameter/feature, skip this step.)

i. Program the Code ID

Example: Set the Code ID of PDF 417 to “p”

1. Check the hex value of “p” in the ASCII Table. (“p”: 70)
 2. Scan the **Enter Setup** barcode.
 3. Scan the **Modify PDF417 Code ID** barcode. (See the “**Modify Code ID**” section in Chapter 6)
 4. Scan the numeric barcodes “7” and “0”.
 5. Scan the **Save** barcode.
 6. Scan the **Exit Setup** barcode. (If you still need to program other parameter/feature, skip this step.)
-

j. Program the NGR Message

Example: Set the NGR message to “!ERR”

1. Check the hex values of “!ERR” in the ASCII Table. (“!ERR”: 21, 45, 52, 52)
2. Scan the **Enter Setup** barcode.
3. Scan the **Edit NGR Message** barcode. (See the “**Edit NGR Message**” section in Chapter 5)
4. Scan the numeric barcodes “2”, “1”, “4”, “5”, “5”, “2”, “5” and “2”.
5. Scan the **Save** barcode.
6. Scan the **Exit Setup** barcode. (If you still need to program other parameter/feature, skip this step.)

k. Program the Length Range (Maximum/Minimum Lengths) for a Symbology

Note: If minimum length is set to be greater than maximum length, the engine only decodes barcodes with either the minimum or maximum length. If you only want to read barcodes with a specific length, set both minimum and maximum lengths to be that desired length.

Example: Set the engine to decode Code 128 barcodes containing between 8 and 12 characters

1. Scan the **Enter Setup** barcode.
 2. Scan the **Set the Minimum Length** barcode. (See the “**Set Length Range for Code 128**” section in Chapter 7)
 3. Scan the numeric barcode “8”.
 4. Scan the **Save** barcode.
 5. Scan the **Set the Maximum Length** barcode. (See the “**Set Length Range for Code 128**” section in Chapter 7)
 6. Scan the numeric barcodes “1” and “2”.
 7. Scan the **Save** barcode.
 8. Scan the **Exit Setup** barcode. (If you still need to program other parameter/feature, skip this step.)
-

Appendix 6: Digit Barcodes

0-9



0000000

0



0000050

5



0000010

1



0000060

6



0000020

2



0000070

7



0000030

3



0000080

8



0000040

4



0000090

9

A-F



A



B



C



D



E



F

Appendix 7: Save/Cancel Barcodes

After reading numeric barcode(s), you need to scan the **Save** barcode to save the data. If you scan the wrong digit(s), you can either scan the **Cancel** barcode and then start the configuration all over again, or scan the **Delete the Last Digit** barcode and then the correct digit, or scan the **Delete All Digits** barcode and then the digits you want.

For instance, after reading the **Maximum Length** barcode and numeric barcodes “1”, “2” and “3”, you scan:

- ✧ **Delete the Last Digit:** The last digit “3” will be removed.
- ✧ **Delete All Digits:** All digits “123” will be removed.
- ✧ **Cancel:** The maximum length configuration will be cancelled. And the engine is still in the setup mode.



0000160

Save



0000170

Delete the Last Digit



0000180

Delete All Digits



0000190

Cancel



Headquarters / 总部

福建新大陆自动识别技术有限公司

地址: 福建省福州市马尾区儒江西路 1 号新大陆科技园

邮编: 350015

电话: +86 - (0) 591-83979222

传真: +86 - (0) 591-83979208

E-mail: marketing@nlscan.com

WEB: www.nlscan.com

Newland Europe BV/ 欧洲新大陆有限公司

Rolweg 25, 4104 AV Culemborg, The Netherlands

TEL: +31 (0) 345 87 00 33

FAX: +31 (0) 345 87 00 39

Email: sales@newland-id.com

WEB: www.newland-id.com

Tech Support: tech-support@newland-id.com

Newland North America Inc. / 北美新大陆有限公司

Address: 46559 Fremont Blvd., Fremont, CA 94538, USA

TEL: 510 490 3888

Fax: 510 490 3887

Email: info@newlandna.com

WEB: www.newlandna.com

Newland Taiwan Inc. / 台湾新大陆资讯科技股份有限公司

7F-6, No. 268, Liancheng Rd., Jhonghe Dist. 235, New Taipei City, Taiwan

新北市 235 中和區連城路 268 號 7 樓之 6 (遠東世紀廣場 J 棟)

TEL: +886 2 7731 5388

FAX: +886 2 7731 5389

Email: sales.tw@newland-id.com